

K281EX001, K281EX002

Installation and operation instruction Thermo-electric actuators normally closed

Instruction
11/2022

Fitting and Re-fitting



NEVER install the actuator in closed position - this may damage the actuator and makes it difficult to install. To ensure that the valve is in an open position during commissioning, all actuators are delivered in a **Normally Open** position and remain in this position until electrically operated first time.

The actuators are as standard supplied with a separate black adaptor ring.

Mount the adaptor ring on top of the valve and finger tighten. Do not use additional tools. If cable plug-in version, be sure cable is properly fitted next. The actuator can now be fitted on the adaptor ring. A click noise will indicate that the actuator is correctly fitted (see figure 1).

In case the actuator will have to be removed, activate the release mechanism. Push the front button and removed the actuator from the adaptor ring.

Please make sure that the actuator is electrically opened, before re-fitting it on the valve.




Figure 1

Orientation

Upside-down installation is allowed along with the standard horizontal and vertical installation.




Figure 2

Wiring




Figure 3

24 V versions must be powered by a safety isolating transformer (for AC variant) according to EN 61558-2-6 or class II FCC-quality proofed or a switching power supply (for DC variant) according to EN 61558-2-16.

Start-up Sequence

During FIRST TIME POWERING operating voltage must be applied for at least 6 minutes.



Imported by GIACOMINI U.K.
Unit 2, Goodrich Close, Westerleigh Business Park,
Yate, South Gloucestershire, BS37 5YT.
✉ support@giacomini.co.uk ☎ 01454311012

Designed and produced by FlowCon International ApS
Trafikcenter Allé 17 / 4200 Slagelse / Denmark

⚠ Safety warning. Installation, commissioning and periodical maintenance of the product must be carried out by qualified operators in compliance with national regulations and/or local standards. A qualified installer must take all required measures, including use of Individual Protection Devices, for his and others' safety. An improper installation may damage people, animals or objects towards which Giacomini S.p.A. may not be held liable.

♻ Package Disposal. Carton boxes: paper recycling. Plastic bags and bubble wrap: plastic recycling.

ℹ Additional information. For more information, go to giacomini.com or contact our technical assistance service. This document provides only general indications. Giacomini S.p.A. may change at any time, without notice and for technical or commercial reasons, the items included herewith. The information included in this technical sheet do not exempt the user from strictly complying with the rules and good practice standards in force.

♻ Product Disposal. Do not dispose of product as municipal waste at the end of its life cycle. Dispose of product at a special recycling platform managed by local authorities or at retailers providing this type of service.



GIACOMINI
WATER E-MOTION



Giacomini S.p.A.
Via per Alzo 39, 28017 San Maurizio d'Opaglio (NO) Italia
✉ consulenza.prodotto@giacomini.com
☎ +39 0322 923372 - giacomini.com